

Programmes en Micropython SmartHome

Test Led pin 12

[exemple001.py](#)

```
from machine import Pin
import time

led = Pin(12, Pin.OUT)# Build an LED object, connect the external LED
light to pin 0, and set pin 0 to output mode
while True:
    led.value(1)# turn on led
    time.sleep(1)# delay 1s
    led.value(0)# turn off led
    time.sleep(1)# delay 1s
```

Test Led PWM

[exemple002.py](#)

```
import time
from machine import Pin,PWM

#The way that the ESP32 PWM pins output is different from traditionally
controllers.
#It can change frequency and duty cycle by configuring PWM's parameters
at the initialization stage.
#Define GPIO 0's output frequency as 10000Hz and its duty cycle as 0,
and assign them to PWM.
p0 = Pin(012, Pin.OUT)
pwm = PWM(p0, freq=10000, duty_u16=8192)

try:
    while True:
        #The range of duty cycle is 0-1023, so we use the first for loop to
control PWM to change the duty
#cycle value,making PWM output 0% -100%; Use the second for loop to
make PWM output 100%-0%.
        for i in range(0,1023):
            pwm.duty(i)
            time.sleep_ms(1)

        for i in range(0,1023):
```

```
        pwm.duty(1023-i)
        time.sleep_ms(1)
except:
    #Each time PWM is used, the hardware Timer will be turned ON to
    #cooperate it. Therefore, after each use of PWM,
    #deinit() needs to be called to turned OFF the timer. Otherwise, the
    #PWM may fail to work next time.
    pwm.deinit()
```

Test des 2 Boutons

[exemple003.py](#)

```
from machine import Pin
import time

button1 = Pin(16, Pin.IN, Pin.PULL_UP)
button2 = Pin(27, Pin.IN, Pin.PULL_UP)

while True:
    btnVal1 = button1.value() # Reads the value of button 1
    btnVal2 = button2.value()
    print("button1 =", btnVal1) #Print it out in the shell
    print("button2 =", btnVal2)
    time.sleep(0.1) #delay 0.1s
```

Test Bouton 1 M/A Led

[exempl004.py](#)

```
from machine import Pin
import time

button1 = Pin(16, Pin.IN, Pin.PULL_UP)
led = Pin(12, Pin.OUT)
count = 0

while True:
    btnVal1 = button1.value() # Reads the value of button 1
    #print("button1 =", btnVal1) #Print it out in the shell
    if(btnVal1 == 0):
        time.sleep(0.01)
        while(btnVal1 == 0):
            btnVal1 = button1.value()
```

```
        if(btnVal1 == 1):
            count = count + 1
            print(count)
    val = count % 2
    if(val == 1):
        led.value(1)
    else:
        led.value(0)
    time.sleep(0.1) #delay 0.1s
```

Test PIR : detection de personnes

[exemple005.py](#)

```
from machine import Pin
import time

PIR = Pin(14, Pin.IN)
while True:
    value = PIR.value()
    print(value, end = " ")
    if value == 1:
        print("Des personnes sont dans la zone ...!")
    else:
        print("il n'y a personne ...!")
    time.sleep(0.1)
```

Test Buzzer Music

[exemple006.py](#)

```
from machine import Pin, PWM
from time import sleep
buzzer = PWM(Pin(25))

buzzer.duty(1000)

# Happy birthday
buzzer.freq(294)
sleep(0.25)
buzzer.freq(440)
sleep(0.25)
buzzer.freq(392)
sleep(0.25)
buzzer.freq(532)
```

```
sleep(0.25)
buzzer.freq(494)
sleep(0.25)
buzzer.freq(392)
sleep(0.25)
buzzer.freq(440)
sleep(0.25)
buzzer.freq(392)
sleep(0.25)
buzzer.freq(587)
sleep(0.25)
buzzer.freq(532)
sleep(0.25)
buzzer.freq(392)
sleep(0.25)
buzzer.freq(784)
sleep(0.25)
buzzer.freq(659)
sleep(0.25)
buzzer.freq(532)
sleep(0.25)
buzzer.freq(494)
sleep(0.25)
buzzer.freq(440)
sleep(0.25)
buzzer.freq(698)
sleep(0.25)
buzzer.freq(659)
sleep(0.25)
buzzer.freq(532)
sleep(0.25)
buzzer.freq(587)
sleep(0.25)
buzzer.freq(532)
sleep(0.5)
buzzer.duty(0)
```

Test Servo Porte entrée : angle 25° 77° 180°

[exemple007.py](#)

```
from machine import Pin, PWM
import time
pwm = PWM(Pin(13))
pwm.freq(50)

...

```

```
Duty cycle corresponding to the Angle
```

```
0°----2.5%----25  
45°----5%----51.2  
90°----7.5%----77  
135°----10%----102.4  
180°----12.5%----128  
...
```

```
angle_0 = 25  
angle_90 = 77  
angle_180 = 128
```

```
while True:  
    pwm.duty(angle_0)  
    time.sleep(1)  
    pwm.duty(angle_90)  
    time.sleep(1)  
    pwm.duty(angle_180)  
    time.sleep(1)
```

Test Capteur Humidité 0= Fenetre Ouverte, 0> Fenetre fermée

[exemple008.py](#)

```
# Import Pin, ADC and DAC modules.  
from machine import ADC, Pin, DAC, PWM  
import time  
pwm = PWM(Pin(5))  
pwm.freq(50)  
  
# Turn on and configure the ADC with the range of 0-3.3V  
adc=ADC(Pin(34))  
adc.atten(ADC.ATTN_11DB)  
adc.width(ADC.WIDTH_12BIT)  
  
# Read ADC value once every 0.1seconds, convert ADC value to DAC value  
# and output it,  
# and print these data to "Shell".  
try:  
    while True:  
        adcVal=adc.read()  
        dacVal=adcVal//16  
        voltage = adcVal / 4095.0 * 3.3  
        print("ADC  
Val:", adcVal, "DACVal:", dacVal, "Voltage:", voltage, "V")  
        if(voltage > 0.6):  
            pwm.duty(46)  
        else:  
            pwm.duty(100)
```

```
time.sleep(0.1)
except:
    pass
```

From: <https://www.fablab37110.chanterie37.fr/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link: <https://www.fablab37110.chanterie37.fr/doku.php?id=start:arduino:esp32:smart:micropython&rev=1740574432>

Last update: **2025/02/26 13:53**

