

# Date et heure dans Node red

## Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**



Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows the configuration interface for a Node-RED inject node. The title is "Modifier le noeud inject". At the top, there are three buttons: "Supprimer", "Annuler", and "Terminer". Below this is a "Propriétés" section with a search bar and three icons. The "Nom" field is set to "Nom". There are two message boxes: "msg.payload" is set to "horodatage" and "msg.topic" is set to "z". At the bottom, there are three options: "Injecter maintenant", "Injecter une fois après 0.1 secondes, puis", and "Répéter" with a dropdown set to "intervalle" and "chaque 1 secondes".

le noeud "Date/Time Formatter" pour la date

### Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

**Propriétés**

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format DD - MM - YYYY

🇫🇷 Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

📄 Topic Topic

🏷️ Name Format date

See the info sidebar for formatting details.  
Use locale and format to change string output.  
See the info sidebar for several warnings about inputting strings.

From: <https://www.fablab37110.chanterie37.fr/> - **Castel'Lab le Fablab MJC de Château-Renault**

Permanent link: <https://www.fablab37110.chanterie37.fr/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004537>

Last update: **2024/01/23 11:08**

