

Date et heure dans Node red

Avec le noeud Date/Time Formater

Il faut dans le menu " Gerer la palette" installer ==> **node-red-contrib-moment**



Dans node-red , mettre les noeuds suivant :



Le noeud "Horodatage"

The screenshot shows a Node-RED configuration window for an inject node. At the top, there are three buttons: 'Supprimer', 'Annuler', and 'Terminer'. Below is a 'Propriétés' section with a 'Nom' field. The main area contains two message properties: 'msg.payload' set to 'horodatage' and 'msg.topic' set to 'a_z'. At the bottom, there are options for 'Injecter une fois après 0.1 secondes, puis' (unchecked) and a 'Répéter' section with 'intervalle' set to 'intervalle' and 'chaque 1 secondes'.

le noeud "Date/Time Formatter" pour la date ==> output format = DD - MM - YYYY et output to = mytime

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

← Input from horodatage

Input Timezone Europe/Paris

Adjustment + 0 Hours

Output Format DD - MM - YYYY

🇫🇷 Locale fr-FR

Output Timezone Europe/Paris

→ Output to msg. mytime

📄 Topic Topic

🏷️ Name Format date

See the info sidebar for formatting details.
Use locale and format to change string output.
See the info sidebar for several warnings about inputting strings.

le noeud "Date/Time Formatter" pour l'heure ==> output format = h - m - s (en minuscule) et msg = mytime

From:

<https://www.fablab37110.chanterie37.fr/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link:

<https://www.fablab37110.chanterie37.fr/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004760>

Last update: 2024/01/23 11:12

