



# Date et heure dans Node red

## Avec le noeud Date/Time Formater

Il faut dans le menu “ Gerer la palette” installer ==> **node-red-contrib-moment**




Dans node-red , mettre les noeuds suivant :



Le noeud “Horodatage”

Last update: 2024/01/23 start:esp32:nodered:heure:nr https://www.fablab37110.chanterie37.fr/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004859  
11:14

---



le noeud “Date/Time Formatter” pour la date ==> Input From = Horodatage Output format = DD - MM - YYYY et Output to = msg.mytime

Modifier le noeud Date/Time Formatter

Supprimer Annuler Terminer

Propriétés

Input from: horodatage

Input Timezone: Europe/Paris

Adjustment: 0 Hours

Output Format: DD - MM - YYYY

Locale: fr-FR

Output Timezone: Europe/Paris

Output to: msg. mytime

Topic: Topic

Name: Format date

See the info sidebar for formatting details.  
Use locale and format to change string output.  
See the info sidebar for several warnings about inputting strings.

le noeud "Date/Time Formatter" pour l'heure ==> Input From = Horodatage Output format = h - m - s ( en minuscule )et Output to = msg.mytime

From:

<https://www.fablab37110.chanterie37.fr/> - Castel'Lab le Fablab MJC de Château-Renault

Permanent link:

<https://www.fablab37110.chanterie37.fr/doku.php?id=start:esp32:nodered:heure:nr&rev=1706004859>

Last update: 2024/01/23 11:14

